
Post War Period





The Austere style of the Post War period reflected the lack of availability of building materials and labour in the years following World War II. Pre-fabricated houses were used to supply demand and simplicity was the key.

Fashionable modern houses of the thirties were sometimes described as being like ocean liners. By the 1940s these details were entrenched into suburban designs. The Waterfall style came to be known as such from the use of descending curves in chimneys, fence pillars and other vertical elements.

After the Second World War, architects in Australia were influenced by the development of the International style of architecture. The houses were typically narrow, linear, and single storey with a low pitched gable roof with exposed rafters and wide eaves.

The triple front cream brick houses of the 1950s and 1960s are distinctly recognisable by their 3, or even 4 front facing walls.

HOW TO ORDER YOUR MOULDING

Ordering your moulding is simple. We just need the answers to a few questions:

- Are you painting or staining your moulding? This will determine which timber you choose. If you are painting, choose Pine or MDF.
- 2. Choose the appropriate timber species
- 3. Choose your moulding number
- 4. Work out the quantity required.

If you wish to match an existing moulding, we require:

- I. A sample or "to scale" drawing
- 2. Timber species required
- 3. Quantity required

Please call our friendly staff on 03 9808 5522 to help you with these questions.

Hazelwood & Hill 80 years

Phone 03 9808 5522 www.hazelwoodhill.com.au

18 McIntyre Street, Burwood Victoria 3125sales@hazelwoodhill.com.auFax (03) 9808 7226

